
Important! This unit is a safety device, and it must be connected to its own separate, fused power point to assure its continued operation should any other electrical accessory fail.


This document provides all the necessary information to allow your product to be properly and safely installed. Before beginning the installation and operation of your new product, the installation technician and operator must read this manual completely.

Mounting


Part #: WB-72601




Bracket tilt Angle 12°




After removing the four screws, the signal assembly can change direction as needed.
Use a 3mm hex wrench.





Signal assembly on the left


Signal assembly on the top


Signal assembly on the right

Wiring Instruction

The wiring for this configuration is as shown in pictures below.



6X16AWG harmess

Cable Color and Wiring Function Table

Red	High beam+heat
Orange	Low beam+heat
White	White PL
Yellow	Amber PL
Green	Direction indicator
Black	GND